



27H9431 - Inner ball joint with tube, fits LH only.

**IMPORTANT:** These diagrams show the view from the driver's seat.

27H9421 - Inner ball joint with thread, fits inner yoke on the RH side.

37H7293 - Outer track rod joint (ball joint) with stem fits both RH & LH stub axle steering arm.

27H9428 - Adjusting tube for track setting and toe-in. This part is normally reused.

37H7293 - Track rod end slides into one end and 27H9421 - Socket assembly, screws into the other.

**NOTE:** These are the track rods closest to the wheels.



**Tractor Spare Parts Ltd**  
Vintage & Classic Tractor Parts